


NS00 No symbol


# Single symbols

Wall mount product


## Lighting




LI01 Dimming




LI02 Floor lamp




LI03 Wall lamp




LI04 Ceiling light pendant




LI05 Spotlight




LI06 Staircase lamp




LI07 Outdoor lighting




LI08 Ceiling light




LI09 Lighting scene




LI10 Wall lamp




LI11 Floor lamp On




LI12 Floor lamp Off




LI13 External light



LI14 General lamp




LI15 Spotlight pendant




LI16 Bulb light


## Multimedia




MU01 Projector screen




MU02 Loudspeaker




MU03 Loudspeaker 2




MU04 Music On




MU05 Sound system




MU06 Sound system 2




MU07 Play




MU08 Stop




MU09 Pause




MU010 Rew



MU011 FFwd




MU012 TV



MU013 Wi-fi


## Health and care



HC01 Buzzer




HC02 Disabled




HC03 First aid



HC04 Disabled 2



























HC05 WC Women







HC06 WC Man











## Door and garage

							
D001 Garage open	D002 Gate	D003 Barrier	D004 Pedestrian entrance	D005 Roller, blind	D006 Internal curtain	D007 External curtain	D008 Door lock
							
D009 Unlock	D0010 Lock	D0011 Roof light windows open	D0012 Roof light window closed	D0013 External curtain 2	D0014 Garage closed	D0015 Garage open	D0016 Curtains open
							
D0017 Window closed	D0018 Window open	D0019 Roller, blind open	D0020 Roller, blind open (50%)	D0021 Roller, blind closed	D0022 Mosquito net	D0023 Curtain with embrasse	D0024 Door lock 2


## Hotel

		DO NOT DISTURB		HOTEL CARD		MAKE UP ROOM
H001 Room service	H002 Service	H003 Do not disturb	H004 Make up room	H005 Hotel Card	H006 Do not disturb card	H007 Make up room 2


## Energy

OFF	ON					
EN01 Power Off	EN02 Power On	EN03 Electric load	EN04 Portable electric load	EN05 Electric socket On/Off	EN06 Electric socket	EN07 Led socket
						
EN08 Car recharge	EN09 Recharge	EN10 Bicycle recharge	EN11 Washingmachine	EN12 Dishwasher		


## Climate



## Scene



## Marker



**Note.** For convenience, all the symbols in this page are shown as they appear on square rockers. The same symbols may also be requested for rectangular rockers.

# Double symbols

Wall mount product

## Markers

NS00 No symbol	DM01 Simple arrow	DM02 Arrow (empty)	DM03 Arrow (empty/full)	DM04 Arrow (full)	DM05 On/Off	DM06 Bullets (empty)	DM07 Bullets (empty/full)
DM08 On/Off (I/O)	DM09 Plus / minus	DM10 Speed 1	DM11 Speed 2	DM12 Speed 3	DM13 Triple bullets (empty/full)	DM14 Volume	
DM15 Triple bullets (empty/full)		DM16 On/Off		DM17 On/Off (I/O)		DM18 Plus / minus	
DM19 Simple arrow		DM20 Arrow (empty)		DM21 Volume			